

PINWOODFER

Copyright © 2019-2023 SubDude Audio LLC, Idaho, USA. All Rights Reserved. Reproduction, transmission or redistribution of this document or its contents without written permission is prohibited.

Take your time, follow the instructions, relax, and enjoy yourself!


WARNINGS: Perform installation with your pinball machine turned off and unplugged from AC power.



**PinWoofers GT Spike-2
Expander Board Delete**

Locate the Expander Board


Shown is the PinWoofers GT Spike-2 Expander Board, and associated Audio Cable that routes to the PinWoofers GT Amplifier.



PINWOOFER

Delete the Expander Board

1. Un-plug the Audio Cable from the Expander Board.
2. Un-plug the Expander Board from the Spike-2 CPU Node Board.
3. Interconnect the 7-wire jumper between CN5 and the header on the PinWoofers Line Out Board.
4. Connect the Ground Loop Isolator between the Audio Cable from the GT Amplifier and the mini-plug jack LINE_OUT on the Line Out Board.



PINWOOFER



You have successfully deleted your PinWoofers GT Expander Board.